

Shutter

Installation Instructions

1. Lay the shutter face down on a soft surface that will not scratch/dent the bracket detail.
2. Apply a 1/2" bead of adhesive caulk all the way around the back edge of the shutter
3. When pressing the shutter up against the surface, some adhesive caulk will seep out. Smooth excess caulk around the shutter with a finger or the putty knife and apply extra caulk that is needed to fill in any gaps.
4. Wipe off any excess adhesive caulk with a sponge or damp rag.
5. Finishing nails may be used for added support. If used, fill in any nail holes with caulk and smooth the surface with a finger. Let any excess caulk dry. Once dry, lightly sand with extra fine sandpaper.
6. Touchup shutter with touchup paint as needed.



IMPORTANT INFO

- It is highly recommended that you paint/finish our shutters before you install them.
- Once installed, you can apply any necessary touch-up paint/finish.
- Clean installation surface and back of the shutter of all dirt and dust with a clean cloth or sponge.
- Make sure that the surface and the back of the shutter are completely dry before attempting installation.
- Measure and mark the location where the shutter is going to be installed.

TOOL CHECKLIST

- construction adhesive
- elastomeric adhesive caulk
- caulking gun
- nail gun
- finishing nails
- extra fine sandpaper
- putty knife



WORTHINGTON[®]
American Made Architectural Products